

Version

1.21

FUJITSU MICROELECTRONICS EUROPE

Development tools for 16LX Family

CPU Board User Guide

DEVELOPMENT TOOLS FOR 16LX FAMILY

CPU Board User Guide

Table of Content

<i>What is in This Guide</i>	2
What is not included in this guide	2
Where to find news, options, OTHER beans, OTHER CPU boards, latest FAQ and support	3
<i>CPU Board Features and Technical Specification</i>	4
Features	4
<i>Flash It!</i>	5
Overview of the DevKit16 FLASH Programming Tool	5
<i>CPU Board Description</i>	6
CPU board overview	6
Connectors	6
Jumpers, buttons and switches	9
Default HW settings	12
<i>CPU Board Power Supply Requirements</i>	13
<i>Warranty and Disclaimer</i>	14
<i>Revision and Error List</i>	15
<i>Appendix</i>	16

What is in This Guide

What you'll find inside this guide and few words about its organization

CPU Board in its interface to the Devkit16 Mainboard is designed in such a way that it is possible to use different CPU boards (with various members of the 16LX family) with the same Mainboard. This guide describes how to use the CPU board as a standalone board.

- **CPU board features and technical specification chapter** provides necessary technical and operational information
- **FLASH It! chapter** explains how to store final application in DevKit16 CPU or external FLASH.
- **CPU Board Description chapter** provides explanation how to control the CPU board configuration and detailed description of CPU board including all DIP switches, jumpers and connectors.
- **Power supply requirements chapter**
- **Revisions and errors list**
- **Appendix** includes schematics of the CPU board and other technical references

WHAT IS NOT INCLUDED IN THIS GUIDE

This guide is not detailed manual for the CPU, parts and software tools. Please find more in the following resources:

- **MCU, Softune Workbench and tools – FUJITSU Micros CD ROM (Ver 3.0 or higher)**
- **Processor Expert^(TM) and tools – DEVKIT16 Software CD ROM**
- **Parts and other HW components – datasheets of their producers**

**WHERE TO FIND NEWS, OPTIONS, OTHER BEANS, OTHER
CPU BOARDS, LATEST FAQ AND SUPPORT**

Please visit DevKit16 WEB site www.processorexpert.com/devkit16 for news and giveaways. You can also register in order to obtain news by mail.

For MCUs and Fujitsu technologies please visit FUJITSU WEB site <http://ww.fujitsu-fme.com>.

When you need additional CPU personality board please call your nearest FUJITSU subsidiary or authorised FUJITSU distributor. You should specify:

- **version of CPU you need**
- **CPU soldered or in socket. Socket version is provided for users who want to use the FUJITSU emulator**

CPU Board Features and Technical Specification

This chapter introduces features of CPU board and provides necessary technical and operational information for DevKit16.

The CPU board was designed as a replaceable part of the Devkit16. So, it contains only few features and the rest is provided by the Devkit16 Mainboard.

FEATURES


- Position for a PQFP 100 processor or NQPACK socket
- connectors for all CPU pins
- a Bus Interface connector for main board connection
- a Device Bus connector
- a power supply supervisor IC with reset generation
- RST, HST buttons
- DIP switch for setting the CPU mode
- High speed (in socket) and low speed quartzes
- Serial port connector
- power supply regulators 5V or 3.3V, depending on CPU used
- power supply connector for external power source and DC power supply circuitry

Flash It!

If the CPU mounted on the CPU board has a FLASH memory, the DevKit16 FLASH Programming Tool can be used to program it.

OVERVIEW OF THE DEVKIT16 FLASH PROGRAMMING TOOL

DevKit16 FLASH Programming Tool provides standard operations (check/program/verify) for CPU Internal FLASH memory, Mainboard FLASH or both.



With the standalone CPU board, it is possible to program only the internal FLASH. The check-box "External bus free ?" should be set to "no" (this tells the SW not to use the FPGA UART). The Flashtool will guide you to set the proper mode on the CPU board DIP switches. The communication will run on 9600Bd only, and only CPU FLASH can be programmed.

For further information, please see the DevKit16 FLASH Programming Tool online Help.

CPU Board Description

This chapter provides detailed description of CPU board including all DIP switches, jumpers and connectors.

CPU board can work standalone or in connection with the Mainboard. If the Mainboard is in use, **please switch all switches on CPU board configuration DIP to OFF.**

C P U B O A R D O V E R V I E W

CPU board is designed as low cost board, which provides compatibility on Interface Bus and the Device Bus level for different CPUs. Additionally, headers pin compatible to CPU pins are provided.

This part contains description of CPU board for MB90F543CPU.

- Connectors
- Jumpers, buttons and switches
- Board layout

C O N N E C T O R S

K1: Bus Interface connector


This connector serves for connecting the CPU board to the Mainboard.

K2: Device Bus connector

This connector provides connection to CPU peripherals.

Note: For the pinout of these connectors, please see the attachments section of this manual.


K7: CPU Serial interface connector



The serial interface connector should be used only when the CPU board is not connected to the mainboard, because mainboard connects its own serial (RS232) interface to the UART0 and UART1 CPU signals. To be able to use the K7 connector, please refer to the description of J7, J8, J9 jumpers later in this section.


Warning: if you want to use the K7 connector when Mainboard is connected to the CPU board, you have to disconnect the serial interface selected by J7-J9 from the RS232 drivers on the Mainboard. To achieve this, remove jumpers on positions 3-4, 5-6 from both the J21 and J22 headers on the Mainboard. Also, when the Async. Serial programming mode is set on the Mainboard *System control DIP switches*, the FPGA UART RS232 driver is connected to UART0 or UART1 (depending on the setting of the UART0/1 switch) after reset. If you want to use K7 also in that case, remove the 3-4, 5-6 jumpers on the J23 as well.

K9: power supply connector




Before applying the power to the Devkit16, check the polarity of your power chord plug – the GND must be in the center, while the +9V on the shell of the connector. Even though the DevKit16 power lines are protected by a diode on the power input, do not ever apply power with the opposite polarity. Also, make sure that the power supply complies to the specifications in chapter *CPU board Power Supply Requirements*.


K3, K4, K5, K6: CPU pins connectors



J10: VCC connector



J11: GND connector



J13: Supply for the whole board

When SHORT, the +5V from the voltage regulator is connected to board VCC. This jumper must be removed when using an external +5V power supply to avoid current flowing back to the regulator.

J2: Supply for CPU

When SHORT, the VCC is connected to CPU's VCC pins. Before removing this jumper, remove the J3 (AVCC to CPU) jumper as well to completely disconnect the power from the CPU.

J3: Analog Supply for CPU

When SHORT, board's VCC is connected to CPU's AVcc pin.

J4: Analog Ground for CPU

When SHORT, board's GND is connected to CPU's AGND pin.

J5: Analog Reference Voltage (+) for CPU

When SHORT, board's VCC is connected to CPU's AVR+ pin. When removed, the voltage at the AVR+ pin is set to 4V

J6: Analog Reference Voltage (-) for CPU

When SHORT, board's GND is connected to CPU's AVR- pin. When removed, the voltage at the AVR- pin is set to 0.9V.

J7, J8, J9: UART0/1 selection for the K7 connector

These jumpers select, which of the two UART0, UART1 interfaces signals will be connected to the pins of the K7 connector. If all of these jumpers are in

1-2 position - the UART1 interface signals will be connected to the K7

2-3 position – the UART0 interface signals will be connected to the K7 connector.

Default setting: the UART1 signals are connected to the K7.

Note: *The J7 jumper selects between SCK1 and SCK0, J8 between SIN1 and SIN0 and J9 between SOT1 and SOT0*

Warning: if you want to use the K7 connector when Mainboard is connected to the CPU board, you have to disconnect the selected serial interface (UART0 or UART1) from the RS232 drivers on the Mainboard. To achieve this, remove jumpers on positions 3-4, 5-6 from both the J21 and J22 headers on the Mainboard. Also, when the Mainboard is connected to the CPU board and the Async. Serial programming mode is set on the Mainboard *System control DIP switches*, the FPGA UART is connected to UART0 or UART1 (depending on the setting of the UART0/1 switch) after reset. If you want to use K7 also in that case, remove the 3-4, 5-6 jumpers on the J23.

J19, J20: I²C software emulation jumpers

These jumpers allow to use Mainboard's I²C connector/EEPROM memory even in the case, when CPU itself doesn't provide the I²C interface. When both of these jumpers are SHORT, the CPU's HRQ signal is connected to the Mainboard's SDA signal (via J19) and #HAK signal is connected to SCL signal. An user can then program the #HAK, HRQ signals to behave as I²C interface.

J15, J16: Low speed XTAL jumpers

When short, these jumpers connect the 32.768 kHz crystal to the Bus Interface connector X1A, X0A pins.

J17, J18: High speed XTAL jumpers

When short, these jumpers connect the 4MHz crystal to the Bus Interface connector X0, X1 pins.

SW1 - Reset button


This button can be used for resetting the CPU.

SW2 - Hardware standby button

While this button is pressed, the CPU stays in the standby mode (all oscillators are stopped, all I/O pins are set to high impedance state, special purpose registers such as the accumulator are reset to their default values, but content of internal RAM is preserved)

SW3 - CPU DIP switches

- 1: MD0
- 2: MD1
- 3: MD2
- 4: S-R
- 5: S-H
- 6: H-R
- 7: AD00 (P00)
- 8: AD01 (P01)



These switches should be used only when using the CPU board without Mainboard, or with the FPGA disabled (see the description of J29 in the Mainboard section).

1:MD0, 2:MD1, 3:MD2 – these switches are connected to CPU pins MD0, MD1, MD2. In the ON position, a switch pulls the signal connected to it to log '0'. The setting of these switches affects the mode of the processor. The description of all the modes is in the following table:

MD2	MD1	MD0	AD00/ P00	AD01 /P01	Mode name	Reset vector area	External data bus width
ON	ON	ON	OFF	OFF	External vector mode 0	External	8
ON	ON	OFF	OFF	OFF	External vector mode 1	External	16
ON	OFF	ON	OFF	OFF	External vector mode 2	External	16
ON	OFF	OFF	OFF	OFF	Internal vector mode	Internal	(Mode data)
OFF	ON	ON	X	X	Reserved		
OFF	ON	OFF	X	X	Reserved		
OFF	OFF	ON	ON	ON	Async serial programming		
OFF	OFF	OFF	X	X	Reserved		

4: S-R – if ON, this switch connects the RES pin of the K7 connector to the CPU's #RST signal.

5: S-H – if ON, this switch connects the RES pin of the K7 connector to the CPU's #HST signal.

6. H-R – if ON, the #RST and #HST signals are connected together.

7: AD00, 8:AD01 – if ON, the AD00/P00 and AD01/P01 signals are pulled to log. '0' level. This setting must be done for bringing processor to the Serial programming mode.




Figure 1: CPU board layout and default jumper settings

DEFAULT HW SETTINGS

These jumpers come in the SHORT position as a default factory setting:

- J2:** The CPU is connected to the +5V power supply through this jumper
- J3:** The CPU AVCC supply pin is connected +5V power supply through this jumper
- J4:** The CPU AGND supply pin is connected to the GND through this jumper
- J5:** The CPU AVR+ pin is connected to the +5V voltage through this jumper
- J6:** The CPU AVR- pin is connected to the 0V voltage through this jumper
- J7-9:** The CPU UART1 signals are connected to the K7 connector
- J13:** The board is powered from the +5V from the power supply voltage regulator
- J19:** The CPU HRQ pin is connected to the SDA Mainboard signal
- J20:** The CPU #HAK pin is connected to the SCL Mainboard signal

CPU Board Power Supply Requirements

CPU board does not come with power supply, please check, if your power supply match the requirements before you plug it to the CPU board!

Power supply voltage: **9V**

Power supply current (CPU board MB90F543 with Main board connected):

- Single chip CPU mode, no external peripheral connected: **290mA max.**
- External bus mode, no peripheral connected: **350mA**
- External bus with:
 - keyboard connected: **450mA** typical, but can vary with the keyboard used (most of modern AT keyboard uses max. 100mA. User should check his keyboard current requirements before connecting the keyboard to the DevKit16 Mainboard).
 - keyboard and VGA interface connected: **650mA**

WE RECOMMEND USING 9V STABILIZED POWER SUPPLY WITH 1.5A (MIN.) OUTPUT CURRENT. IF THE POWER SUPPLY CAN NOT DELIVER CURRENTS AS SPECIFIED IN THE SPECIFICATION ABOVE, THE DEVKIT16 WILL NOT WORK PROPERLY - THE BOARD WILL BE PERIODICALLY RESET BY THE MB3771 POWER SUPPLY SUPERVISOR.

Warning: If the DevKit16 is powered using the on-board stabilizer, the supply current must not exceed the 1A limit of the stabilizer. Before connecting any peripheral to the DevKit16, please check that its power supply current requirements doesn't does not cause this limit to be exceeded.

Warranty and Disclaimer

To the maximum extent permitted by applicable law, Fujitsu Microelectronics Europe GmbH restricts its warranties and its liability for the **DEVKIT16 and all its deliverables** (eg. software, application examples, target boards, evaluation boards, etc.), its performance and any consequential damages, on the use of the Product in accordance with (i) the terms of the License Agreement and the Sale and Purchase Agreement under which agreements the Product has been delivered, (ii) the technical descriptions and (iii) all accompanying written materials. In addition, to the maximum extent permitted by applicable law, Fujitsu Microelectronics Europe GmbH disclaims all warranties and liabilities for the performance of the Product and any consequential damages in cases of unauthorised decompiling and/or reverse engineering and/or disassembling. **Note, the DEVKIT16 and all its deliverables are intended and must only be used in an evaluation laboratory environment.**

1. Fujitsu Microelectronics Europe GmbH warrants that the Product will perform substantially in accordance with the accompanying written materials for a period of 90 days from the date of receipt by the customer. Concerning the hardware components of the Product, Fujitsu Microelectronics Europe GmbH warrants that the Product will be free from defects in material and workmanship under use and service as specified in the accompanying written materials for a duration of 1 year from the date of receipt by the customer.
2. Should a Product turn out to be defect, Fujitsu Microelectronics Europe GmbH's entire liability and the customer's exclusive remedy shall be, at Fujitsu Microelectronics Europe GmbH's sole discretion, either return of the purchase price and the license fee, or replacement of the Product or parts thereof, if the Product is returned to Fujitsu Microelectronics Europe GmbH in original packing and without further defects resulting from the customer's use or the transport. However, this warranty is excluded if the defect has resulted from an accident not attributable to Fujitsu Microelectronics Europe GmbH, or abuse or misapplication attributable to the customer or any other third party not relating to Fujitsu Microelectronics Europe GmbH.
3. To the maximum extent permitted by applicable law Fujitsu Microelectronics Europe GmbH disclaims all other warranties, whether expressed or implied, in particular, but not limited to, warranties of merchantability and fitness for a particular purpose for which the Product is not designated.
4. To the maximum extent permitted by applicable law, Fujitsu Microelectronics Europe GmbH's and its suppliers' liability is restricted to intention and gross negligence.

NO LIABILITY FOR CONSEQUENTIAL DAMAGES

To the maximum extent permitted by applicable law, in no event shall Fujitsu Microelectronics Europe GmbH and its suppliers be liable for any damages whatsoever (including but without limitation, consequential and/or indirect damages for personal injury, assets of substantial value, loss of profits, interruption of business operation, loss of information, or any other monetary or pecuniary loss) arising from the use of the Product.

Should one of the above stipulations be or become invalid and/or unenforceable, the remaining stipulations shall stay in full effect.

Revision and Error List

The following bugs have been found with the board and need to be observed when working with this tool:

Date	Revisions - Errors	Revised Version
05.11.1999	Version 1.2 is valid for CPU Board ver. 1.3	V1.2
13.02.2000	The table “Device Bus (K2) and Interface Bus (K1) connectors pins” (pages 16, 17, 18) was not consistent with the schematics.	V1.21

Table1: List of found errors and revisions for version V1.2

Appendix

Here you will find Interface bus and Device Bus description and CPU board schematics.

Device Bus (K2) and Interface Bus (K1) connectors pins:

DIN Conn. PIN	Device Bus		Interface Bus		
	PIN NO.	CPU Pin Nr.	Function	CPU PIN Nr.	SIGNAL
A1	18	SOT0	85	AD00	P00
B1	19	SCK0	86	AD01	P01
C1	20	SIN0	87	AD02	P02
A2	24	SOT1	88	AD03	P03
B2	22	SCK1	89	AD04	P04
C2	21	SIN1	90	AD05	P05
A3			91	AD06	P06
B3			92	AD07	P07
C3			93	AD08	P10
A4	69	INT0	94	AD09	P11
B4	70	INT1	95	AD10	P12
C4	71	INT2	96	AD11	P13
A5	72	INT3	97	AD12	P14
B5	29	INT4	98	AD13	P15
C5	30	INT5	99	AD14	P16
A6	31	INT6	100	AD15	P17
B6	32	INT7	1	A16	P20
C6	25	SOT2	2	A17	P21
A7	26	SCK2	3	A18	P22
B7	28	SIN2	4	A19	P23
C7			5	A20	P24
A8			6	A21	P25
B8			7	A22	P26
C8			8	A23	P27
A9			9	ALE	P30
B9			10	\RD	P31
C9			12	\WRL	P32
A10			13	\WRH	P33
B10			14	HRQ	P34

DIN Conn. PIN	Device Bus		Interface Bus			
	PIN NO.	CPU Pin Nr.	Function	CPU PIN Nr.	SIGNAL	2nd Function
C10				15	\HAK	P35
A11	47	TIN0		16	RDY	P36
B11	48	TOT0		17	CLK	P37
C11		GND			GND	GND
A12	67	TIN1		18	SOT0	P40
B12	68	TOT1		19	SCK0	P41
C12				20	SIN0	P42
A13				24	SOT1	P45
B13	53	IN0		22	SCK1	P44
C13	54	IN1		21	SIN1	P43
A14	55	IN2		25	SOT2	P46
B14	56	IN3		26	SCK2	P47
C14	57	IN4		28	SIN2	P50
A15	58	IN5			SDA	
B15	59	OUT2/IN6			SCL	
C15	60	OUT3/IN7	61		PPG0	P80
A16	65	OUT0	62		PPG1	P81
B16	66	OUT1	67		TIN1	P86
C16		VCC			VCC	
A17	59	OUT3/IN7	33		ADTG	P55
C17	60	OUT2/IN6	68		TOT1	P87
C17		AVCC	34		AVCC	
A18			35		AVR+	
B18			36		AVR-	
C18		AGND	37		AGND	
A19			38		AN0	P60
B19			39		AN1	P61
C19		GND			GND	GND
C20			40		AN2	P62
A21			41		AN3	P63
C20			43		AN4	P64
A21			44		AN5	P65
B21			45		AN6	P66
C21			46		AN7	P67
A22	61	PPG0	77		\RST	
B22	62	PPG1	52		\HST	
C22	63	PPG2	69		INT0	P90
A23	64	PPG3	70		INT1	P91
B23			71		INT2	P92
C23			72		INT3	P93
A24	73	TX0	29		INT4	P51
B24	74	RX0	30		INT5	P52
C24	75	TX1	31		INT6	P53
A25	76	RX1	32		INT7	P54
B25			53		IN0	P70
C25			54		IN1	P71
A26			55		IN2	P72
B26			56		IN3	P73
C26			59		OUT2/IN6	P76
A27			60		OUT3/IN7	P77
B27					NC(SGO)	
C27					NC(SGA)	

DIN Conn. PIN	Device Bus		Interface Bus		
	PIN NO.	CPU Pin Nr.	Function	CPU PIN Nr.	SIGNAL
A28			73	TX0	P94
B28			74	RX0	P95
C28			75	TX1	P96
A29			76	RX1	P97
B29			79	X1AJ	
C29			80	X0AJ	
A30			82	X0J	
B30			83	X1J	
C30		VCC		VCC	
A31			49	MD0	
B31			50	MD1	
C31				NC	
A32			51	MD2	
B32				NC	
C32		GND		GND	

